

Compatible Inverter List



LR5000



LW5000



HS5000



HT5000

LR5000
LW5000

HT5000
HS5000

BATTERY	BRAND	MODEL	NOTES
	GROWATT	SPF5000ES (off-grid) SPH5000TL BL-UP	Single-phase; Low voltage
	SMA	Sunny Island 6.0H	Single-phase; Low voltage
	VICTRON	MultiPlus-II	Single-phase; Low voltage
	SOLIS	S6-EH1P5K-L-EU	Single-phase; Low voltage
	SOFAR	HYD5000-EP	Single-phase; Low voltage
	GOODWE	GW5048D-ES	Single-phase; Low voltage
	AFORE	AF1K-SL-1\15K-SL-1\2K-SL-1\ 2.5K-SL-1\3K-SL-1\36K-SL-1 AF1K-SL-0\15K-SL-0\ 2K-SL-0\2.5K-SL-0	Single-phase; Low voltage
	DEYE	SUN-5K-SG03LP1-EU SUN-6K-SG03LP1-EU SUN-12K-SG04LP3-EU	Single-phase; Low voltage Three-phase; Low voltage
	HYPONTECH	HES-3000\3680\4000\5000\6000	Single-phase; Low voltage; AC-coupled
	MEGAREVO	R6KL1\R8KL1\R8KLNA	Single-phase; Low voltage
	INHENERGY	HI-6K-SL	Single-phase; Low voltage
	GROWATT	SPH 10000TL3 BH-UP	Three-phase; High voltage
	SOLIS	S6-EH3P10K-H-EU	Three-phase; High voltage
	SOFAR	HYD 10KTL-3PH	Three-phase; High voltage
	GOODWE	GW10KN-ET	Three-phase; High voltage
	SUNGROW	SH10RT	Three-phase; High voltage
	SINENG	SN3.0HS\SN3.68HS SN4.0HS\SN5.0HS\SN6.0HS	Three-phase; High voltage
	AFORE	AFX-TH 25K	Three-phase; High voltage
	DEYE	DEYE SUN-20K-SG01HP3-EU-AM2	Three-phase; High voltage
		HHS-3000\3480\5000\6000	Single-phase; High voltage
		HBS-3000\3480\5000\6000	Single-phase; High voltage; AC-coupled
	HYPONTECH	HHT-5000\6000\8000\10000\12000\15000 HBT-5000\6000\8000\10000\12000\15000	Three-phase; High voltage
	MEGAREVO	R10KH3	Three-phase; High voltage